

Installation Instructions

Plaster Curved Wall Lights



Models: T6112, T6276, T6277, T6216, T6223, T7525, T6213, T6313, T6802, T6220, T6218, T6119, T6211, T6123, T6122, T6118, T6118, T6116, T6117, T6101, T6115

We recommend all fittings are installed by a qualified electrician. Ensure the electrical supply is disconnected at the consumer unit/fuse board before you begin.

Important: All of our plaster lights can be left unpainted, however if you do decide to paint them, it is necessary to first seal them with a PVA sealer. A solution can be made up by mixing 1 part PVA with 1 part water. Use a brush to apply the sealer, then wait until thoroughly dry before painting. After lights have been painted, please allow 2-3 days before switching on any warm light source such as tungsten halogen.

