

Installation Instructions

Plaster Linear Wall Lights

Models: TR9281, TR7726



We recommend all fittings are installed by a qualified electrician. Ensure the electrical supply is disconnected at the consumer unit/fuse board before you begin.

Important: All of our plaster lights can be left unpainted, however if you do decide to paint them, it is necessary to first seal them with a PVA sealer. A solution can be made up by mixing 1 part PVA with 1 part water. Use a brush to apply the sealer, then wait until thoroughly dry before painting. After lights have been painted, please allow 2-3 days before switching on any warm light source such as tungsten halogen.

